




GEMINI



User Manual

Please read the instruction carefully before use

CONTENTS

01/ Safety Instructions.....	2
02/ Technical Specifications	6
03/ Control Panel.....	8
04/ Fixture Installation.....	9
05/ How To Set The Unit.....	11
5.1 Main Functions	11
5.2 Home Position Adjustment	25
06/ Control By Universal DMX Controller	29
6.1 DMX512 Connection.....	29
6.2 Address Setting.....	30
6.3 DMX512 Configuration.....	30
07/ Error Information	44
08/ Troubleshooting	47
09/ Fixture Cleaning	48

01/ Safety Instructions



Please read the instruction carefully which includes important information about the installation, usage and maintenance.

WARNING

Please keep this User Guide for future consultation. If you sell the unit to another user, be sure that they also receive this instruction manual.

Important:

Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems.

- Unpack and check carefully to ensure that there is no transportation damage before using the unit.
- This product is for indoor use only. Use only in a dry location.
- DO install and operate by qualified operator.
- DO NOT allow children to operate the fixture.
- Use safety chain (made of steel, min. diameter 2.0mm) when fixing the unit. Handle the unit by carrying its base instead of head only.
- The unit must be installed in a location with adequate ventilation, at least 50cm from adjacent surfaces.
- Be sure that no ventilation slots is blocked, otherwise the unit will be overheated.
- Before operation, ensure that you are connecting this product to the proper voltage in accordance with the specifications in this manual or on the product's specification label.
- It's important to ground the yellow/green conductor to earth in order to avoid electric shock.
- Minimum ambient temperature TA: 0°C. Maximum ambient temperature TA: 40°C. Do not operate this product at a lower or higher temperature.
- DO NOT connect the device to any dimmer pack.
- Keep flammable materials away from the fixture while operating to avoid fire hazard.
- Make sure the power cord is not crimped or damaged; replace it immediately if damaged.
- Unit's surface temperature may reach up to 75°C. DO NOT touch the housing bare-handed during its operation.
- Avoid any flammable liquids, water or metal from entering the unit. Once it happens, cut

off the mains power immediately.

- DO NOT operate in a dirty or dusty environment. DO clean the fixture regularly.
- DO NOT touch any wire during operation as there might be a hazard of electric shock.
- Avoid entanglement of the power cord with other wires.
- The minimum distance to objects/surface must be more than 0.5 meters.
- Disconnect mains power before fuse replacement or servicing.
- Replace fuse only with the same type.
- In the event of serious operating problem, stop using the unit immediately.
- Never turn on and off the unit time after time.
- The housing, the lenses, or the ultraviolet filter must be replaced if they are visibly damaged.
- DO NOT open the housing as there are no user serviceable parts inside.
- DO NOT attempt to operate this unit if it becomes damaged. DO NOT attempt any repairs yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center if needed.
- Disconnect this product from its power source before servicing.
- DO use the original packaging if the device is to be transported.
- Avoid direct eye exposure to the light source while the product is on.
- DO NOT operate this product if you see damage on the housing, shields, or cables. Have the damaged parts replaced by an authorized technician at once.

01/ Consignes de sécurité



Veuillez lire attentivement les instructions qui contiennent des informations importantes sur l'installation, l'utilisation et l'entretien.

ATTENTION

Veuillez conserver ce guide de l'utilisateur pour une consultation future. Si vous vendez l'appareil à un autre utilisateur, assurez-vous qu'il reçoive également ce manuel d'instructions.

Important:

Les dommages causés par le non-respect de ce manuel d'utilisation ne sont pas couverts par la garantie. Le revendeur n'acceptera aucune responsabilité pour les défauts ou problèmes qui en résultent.

- Déballez et vérifiez soigneusement qu'il n'y a pas de dommages dus au transport avant d'utiliser l'appareil.
- Ce produit est destiné à un usage intérieur uniquement. Il doit donc être utilisé uniquement dans un endroit sec.
- L'installation et la mise en fonctionnement doit être effectué par un opérateur qualifié.
- NE PAS permettre aux enfants d'utiliser l'appareil.
- Utilisez une chaîne de sécurité lors de la fixation de l'unité. Manipulez l'appareil en portant sa base au lieu de la tête uniquement.
- L'unité doit être installée dans un endroit avec une ventilation adéquate, à au moins 50cm des surfaces adjacentes.
- Assurez-vous qu'aucune fente d'aération du luminaire n'est obstruée, sinon il risque de surchauffer.
- Avant toute utilisation, assurez-vous que vous connectez ce luminaire à la tension appropriée conformément aux spécifications que vous trouverez dans ce manuel ou sur l'étiquette des spécifications collée sur la base du luminaire.
- Il est important de relier le file jaune/vert à la terre afin d'éviter tout choc électrique.
- Température ambiante minimale TA: 0°C. Température ambiante maximale TA: 40°C.
N'utilisez pas ce luminaire à des températures inférieures ou supérieures.
- NE PAS connecter le luminaire à un pack de gradateurs.
- Gardez les matériaux inflammables à l'écart du luminaire pendant le fonctionnement



pour éviter tout risque d'incendie.

- Assurez-vous que le cordon d'alimentation n'est pas pincé ou endommagé; remplacez-le immédiatement s'il est endommagé.
- La température de surface de l'unité peut atteindre 75°C. NE PAS toucher les capots à mains nues pendant son fonctionnement.
- Évitez que des liquides inflammables, de l'eau ou du métal ne pénètrent dans l'appareil. Si cela se produit, coupez immédiatement l'alimentation secteur.
- NE PAS utiliser le luminaire dans un environnement sale ou poussiéreux. Cette appareil doit être nettoyer régulièrement.
- NE touchez AUCUN fil pendant le fonctionnement car il pourrait y avoir un risque de choc électrique.
- Évitez l'enchevêtrement du cordon d'alimentation avec d'autres fils.
- La distance minimale de projection sur des objets ou sur des surfaces doit être supérieure à 0.5 mètres.
- Débranchez l'alimentation secteur avant le remplacement ou l'entretien des fusibles.
- Remplacez le fusible uniquement par un fusible du même type.
- En cas de problème de fonctionnement grave, arrêtez immédiatement d'utiliser l'appareil.
- N'allumez et n'éteignez jamais ce luminaire à maintes reprises.
- Le boîtier, les lentilles ou le filtre ultraviolet doivent être remplacés s'ils sont visiblement endommagés.
- NE PAS ouvrir le boîtier car il ne contient aucune pièce réparable par l'utilisateur.
- NE PAS mettre ce luminaire en fonctionnement s'il est endommagé. N'effectuez pas de réparations vous-même. Les réparations ne doivent être effectuées par des personnes non qualifiées, cela peut entraîner des dommages ou des dysfonctionnements. Veuillez contacter le centre d'assistance technique agréé le plus proche si nécessaire.
- Débranchez ce produit du secteur avant de procéder à l'entretien.
- Utiliser l'emballage d'origine si l'appareil doit être transporté.
- Évitez une exposition directe des yeux à la source lumineuse lorsque le produit est allumé.
- N'utilisez PAS ce produit si vous constatez des dommages sur le boîtier, les blindages ou les câbles. Faites remplacer immédiatement les pièces endommagées par un technicien agréé.



02/ Technical Specifications

Power Voltage	100-240V~ 50/60Hz	
Power Consumption	1240W	
Light Source	5x60W RGBW LED 36x18W CW LED	
Beam Angle	2.8°-31° (beam section) 96° (strobe section)	
Field Angle	5°-46° (beam section) 116° (strobe section)	
Dimmer/Strobe	0-100% smooth dimming; outstanding strobe effect with variable speed	
Movement	Pan	Infinite
	Tilt	Infinite
	Pan/Tilt Resolution	16 bit
	Automatic pan/tilt position correction	
	Fixation	Pan/Tilt lock
Control	DMX Channel	58/25/23/35+/27/70/55 Channels
	Control Mode	DMX512
		RDM
		Art-Net
		sACN
	Firmware Upgrade	Firmware Upgrade via DMX link
Construction	Display	LCD display
	Battery backup for user setup without mains connection	
	Data In/Out	5-pin XLR (3-pin XLR is optional)
		RJ45 Connector
	Power In/Out	Power Connector in/out
	Protection Rating	IP20


Features	With zoom and strobe functions	
	Beam section: 5 x RGBW LEDs with individual control	
	Strobe section: 18 x CW LED zones with individual control	
	Variable CTO	
	Outstanding color mixing effect	
	Supplied with two omega brackets (optional with two fixed foldable clamps)	
Dimensions	500x223x388.4 mm (version with omega bracket holes)	19.7"x8.8"x15.3"
Dimensions	500x223x420.4 mm (version with fixed foldable clamps)	19.7"x8.8"x16.6"
Weight	19.2 kg (version with omega bracket holes)	42.3 lbs
Weight	20.3 kg (version with fixed foldable clamps)	44.8 lbs



Photometric Diagram:




03/ Control Panel




1. Display	To show the various menus and the selected function								
2. Buttons	<table border="1"> <tr> <td>MENU</td><td>To enter into move backward or leave the menu</td></tr> <tr> <td>▲ UP</td><td>To go backward to move up in the menu</td></tr> <tr> <td>▼ DOWN</td><td>To go forward to move down in the menu</td></tr> <tr> <td>ENTER</td><td>To perform the desired functions</td></tr> </table>	MENU	To enter into move backward or leave the menu	▲ UP	To go backward to move up in the menu	▼ DOWN	To go forward to move down in the menu	ENTER	To perform the desired functions
MENU	To enter into move backward or leave the menu								
▲ UP	To go backward to move up in the menu								
▼ DOWN	To go forward to move down in the menu								
ENTER	To perform the desired functions								
3. BATTERY DISPLAY									
4. ETHERNET	Transfers fixture's information to a main controller								
5. DMX IN	For DMX512 link, use 5-pin XLR cable to link the unit and DMX controller to input DMX signal (3-pin XLR cable is optional)								
6. DMX OUT	For DMX512 link, use 5-pin XLR cable to link the next units to output DMX signal (3-pin XLR cable is optional)								
7. POWERCON IN	To connect to supply power								
8. POWERCON OUT	To connect to the next fixture								
9. FUSE(T 15A)	Protects the unit from damage of over current or short circuit								

04/ Fixture Installation

- ▶ DO install and operate by qualified operator. Fixture(s) should be installed in areas outside walking paths, seating areas, or away from areas where unauthorized personnel might reach the fixture by hand. NEVER stand directly below the fixture(s) when rigging, removing or servicing.
- ▶ Always ensure that the unit is firmly fixed to avoid vibration and slipping off during operation. Ensure that the trussing or area of installation must be able to hold 10 times the weight without any deformation. Always attach a safety cable (made of steel, min. diameter 2.0mm) that can hold at least 12 times the weight of the fixture whenever installing this fixture in a suspended environment to ensure that the fixture will not fall if the clamp fails.
- ▶ This fixture is fully operational in three different mounting positions: hanging upside-down, mounted sideways on trussing, or standing on the floor. Always use and install a safety cable as a safety measure to prevent accidental damage and/or injury in the event the clamp fails.



Steps for installing omega brackets to the fixture:



05/ How To Set The Unit

5.1 Main Functions

- ▶ To access the control menus, press the [MENU] button.
- ▶ Navigate the menu structure, using the [ENTER], [**▲ UP**] and [**▼ DOWN**] buttons.
- ▶ To select a menu option or to confirm a selection, press the [ENTER] button.
- ▶ To return to a higher level in the menu structure without making a change, press the [MENU] button, or wait 30 seconds.

The main functions are shown below:

MENU	SUBMENU	OPTIONS
DMX Settings	DMX Address	1-455 (58 CH)
		1-488 (25 CH)
		1-490 (23 CH)
		1-478 (35+ CH)
		1-486 (27 CH)
		1-443 (70 CH)
		1-458 (55 CH)
	Mode 4 ART Addr	1-493 (35+ CH) (Default=1)
	DMX Channel Mode	58 CH
		25 CH
		23 CH
		35+ CH
		27 CH
		70 CH
		55 CH
	No DMX Status	Blackout
		Hold
		Manual
	View DMX Value	
	Connect Option	Auto
		DMX
		Art-Net
		sACN

MENU	SUBMENU	OPTIONS		
	Network	IP Address	Default 1:002.xxx.xxx.xxx	
			Default 2:010.xxx.xxx.xxx	
			Manual:xxx.xxx.xxx.xxx	
	Art-Net Settings	Subnet Mask	xxx.xxx.xxx.xxx	
		Net	0-127	(Default=0)
		Sub-Net	0-15	(Default=0)
		Universe	0-15	(Default=0)
	sACN Settings	sACN Universe	1-32000	(Default=1)
		sACN Priority	0-200	(Default=100)
	Network to DMX	No		
		Yes		
Fixture Settings	Pan Invert	No		
		Yes		
	Tilt Invert	No		
		Yes		
	P/T Feedback	No		
		Yes		
	Dimmer Curve	Linear		
		Square Law		
		Inv SQ Law		
		S Curve		
	Dimmer Speed	Fast		
		Smooth		
	White Balance	Red	125-255	
		Green	125-255	
		Blue	125-255	
		Red 1	125-255	
		Green 1	125-255	
		Blue 1	125-255	
		
		Red 5	125-255	
		Green 5	125-255	
		Blue 5	125-255	
	Invert Pixel Order	Disable		
		Enable		
	Line Power Mode	Off		
		On		

MENU	SUBMENU	OPTIONS						
Display Settings	Display Invert	No						
		Yes						
	Backlight Intensity	1-10	(Default=10)					
		°C						
	Temperature Unit	°F						
		English						
Fixture Test	Language	Chinese						
		Single						
	Auto Test	Cycle						
			Mode 1	Mode 2				
		Clear	No/Yes	Clear	No/Yes			
		Pan	0-255	Pan	0-255			
		Tilt	0-255	Tilt	0-255			
		Pan Infinity	0-255	Pan Infinity	0-255			
		Tilt Infinity	0-255	Tilt Infinity	0-255			
		R LED 1	0-255	R LED	0-255			
		G LED 1	0-255	G LED	0-255			
		B LED 1	0-255	B LED	0-255			
		W LED 1	0-255	W LED	0-255			
		CTO	0-255			
		R LED 5	0-255	Color Macro	0-255			
		G LED 5	0-255	Zoom	0-255			
		B LED 5	0-255	Strobe	0-255			
		W LED 5	0-255	Dimmer	0-255			
	Manual Test	LED W 1	0-255	Intensity	0-255			
		Duration	0-255			
		LED W 18	0-255	Rate	0-255			
		Intensity	0-255	Effects	0-255			
		Duration	0-255					
		Rate	0-255					
		Effects	0-255					
		Zoom	0-255					
		Strobe	0-255					
		Dimmer	0-255					

MENU	SUBMENU	OPTIONS			
Fixture Information	Fixture Use Hour				
	LED Use Hour	Total LED Hour			
		LED On Hour			
	Temperature	LED Hours Reset		Password=050	
		LED's	Cur	Max	
			LED 1		
			LED 2		
	Fan State	PCBA	CPU-A		
			CPU-B		
			CPU-C		
			CPU-D		
Reset Function	Firmware Version	B_FAN 1-2			
		H_FAN 1-5			
	RDM UID				
	Error Logs	Fixture Errors			
		Reset Error Log		No	
			Yes	Yes	Password=050
Special Function	Pan/Tilt Reset	No			
		Yes			
	Effect Reset	No			
		Yes			
	All Reset	No			
		Yes			
	Factory Restore	No			
		Yes			

DMX Settings

Enter the control menu and select **DMX Settings**, press ENTER. Use the UP/DOWN button to select **DMX Address**, **Mode 4 ART Addr**, **DMX Channel Mode**, **No DMX Status**, **View DMX Value**, **Connect Option**, **Network**, **Art-Net Settings**, **sACN Settings** or **Network to DMX**.

DMX Address

Select **DMX Address**, press ENTER.

Use UP/DOWN button to select an address, confirm your selection with ENTER.

CHANNEL MODE	DMX ADDRESS
58 CH	1-455
25 CH	1-488
23 CH	1-490
35+ CH	1-478
27 CH	1-486
70 CH	1-443
55 CH	1-458

To exit the menu, press MENU, or wait 30 seconds.

Mode 4 ART Addr

Select **Mode 4 ART Addr**, press ENTER.

Use UP/DOWN button to select an address, confirm your selection with ENTER.

CHANNEL MODE	ADDRESS
35+ CH	1-493

To exit the menu, press MENU, or wait 30 seconds.

DMX Channel Mode

Select **DMX Channel Mode**, press ENTER.

Use UP/DOWN button to select between **58 CH**, **25 CH**, **23 CH**, **35+ CH**, **27 CH**, **70 CH** and **55 CH**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

No DMX Status

Select **No DMX Status**, press ENTER.

Use UP/DOWN button to select one of the following status:

Blackout (Fixture blacks out if DMX signal stops)

Hold (The device continues to operate in the current mode with the last active DMX values until the signal returns)

Manual (The device accepts the DMX value stored in the 'Manual Test' menu)

Confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

View DMX Value

Select **View DMX Value**, press ENTER.

Use UP/DOWN button to select the desired DMX channel, for which the value is to be displayed.

To exit the menu, press MENU, or wait 30 seconds.

Connect Option

Select **Connect Option**, press ENTER.

Use UP/DOWN button to select **Auto**, **DMX**, **Art-Net** or **sACN**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Network

Select **Network**, press ENTER.

Use UP/DOWN button to select **IP Address** or **Subnet Mask**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Art-Net Settings

Select **Art-Net Settings**, press ENTER.

Use UP/DOWN button to select **Net**, **Sub-Net** or **Universe**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

sACN Settings

Select **sACN Settings**, press ENTER.

Use UP/DOWN button to select **sACN Universe** or **sACN Priority**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Network to DMX

Select **Network to DMX**, press ENTER.

Use UP/DOWN button to select **No** or **Yes**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Fixture Settings

Enter the control menu and select **Fixture Settings**, press ENTER. Use the UP/DOWN button to select **Pan Invert**, **Tilt Invert**, **P/T Feedback**, **Dimmer Curve**, **Dimmer Speed**, **White Balance**, **Invert Pixel Order** or **Line Power Mode**.

Pan Invert

Select **Pan Invert**, press ENTER.

Use UP/DOWN button to select **No** (pan invert deactivated) or **Yes** (pan invert activated), confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Tilt Invert

Select **Tilt Invert**, press ENTER.

Use UP/DOWN button to select **No** (tilt invert deactivated) or **Yes** (tilt invert activated), confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

P/T Feedback

Select **P/T Feedback**, press ENTER.

Use UP/DOWN button to select **No** (pan/tilt feedback deactivated) or **Yes** (pan/tilt feedback activated), confirm your selection with ENTER.


To exit the menu, press MENU, or wait 30 seconds.

Dimmer Curve


Select **Dimmer Curve**, press ENTER.

Use UP/DOWN button to select **Linear**, **Square Law**, **Inv SQ Law** or **S Curve**, confirm your selection with ENTER.


Dimmer Modes




Optically Linear



Square Law



Inverse Square Law



S-curve

To exit the menu, press MENU, or wait 30 seconds.

Dimmer Speed

Select **Dimmer Speed**, press ENTER.

Use UP/DOWN button to select **Fast** or **Smooth**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

White Balance

Select **White Balance**, press ENTER.

Use UP/DOWN button to select **Red**, **Green**, **Blue**, **Red 1**, **Green 1**, **Blue 1**..... or **Red 5**, **Green 5**, **Blue 5**, confirm your selection with ENTER.

Use UP/DOWN button to select a value between **125** and **255**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Invert Pixel Order

Select **Invert Pixel Order**, press ENTER.

Use UP/DOWN button to select **Disable** or **Enable**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Line Power Mode

Select **Line Power Mode**, press ENTER.

Use UP/DOWN button to select **Off** or **On**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Display Settings

Enter the control menu and select **Display Settings**, press ENTER. Use the UP/DOWN button to select **Display Invert**, **Backlight Intensity**, **Temperature Unit** or **Language**.

Display Invert

Select **Display Invert**, press ENTER.

Use UP/DOWN button to select **No** (display normal) or **Yes** (display inverted), confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Backlight Intensity

Select **Backlight Intensity**, press ENTER.

Use UP/DOWN button to select a value between **1** (dark) and **10** (bright), confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Temperature Unit

Select **Temperature Unit**, press ENTER.

Use UP/DOWN button to select **°C** or **°F**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Language

Select **Language**, press ENTER.

Use UP/DOWN button to select **English** or **Chinese**, confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Fixture Test

Enter the control menu and select **Fixture Test**, press ENTER. Use the UP/DOWN button to select **Auto Test** or **Manual Test**.

Auto Test

Select **Auto Test**, press ENTER.

Use UP/DOWN button to select **Single** (the device immediately performs a single automatic self-test) or **Cycle** (the device immediately performs a cyclic automatic self-test), confirm your selection with ENTER.

To exit the menu, press MENU.

Manual Test

Select **Manual Test**, press ENTER.

Use UP/DOWN button to select the channel for which the manual test is to be performed, confirm your selection with ENTER.

Use UP/DOWN button to select a value, confirm your selection with ENTER.

To exit the menu, press MENU.

(The device returns to its original DMX state after the manual test. The test values are saved automatically when the device is switched off.)

Fixture Information

Enter the control menu and select **Fixture Information**, press ENTER. Use the UP/DOWN button to select **Fixture Use Hour**, **LED Use Hour**, **Temperature**, **Fan State**, **Firmware Version**, **RDM UID** or **Error Logs**.

Fixture Use Hour

Select **Fixture Use Hour**, press ENTER.

The operating hours is displayed.

To exit the menu, press MENU, or wait 30 seconds.

LED Use Hour

Select **LED Use Hour**, press ENTER.

Use UP/DOWN button to select **Total LED Hour** (total time) or **LED On Hour** (current switch-on time), confirm your selection with ENTER.

The total time or current switch-on time is displayed.

Use UP/DOWN button to select **LED Hours Reset**, confirm your selection with ENTER.

Use UP/DOWN button to set the password 050, confirm your selection with ENTER. The LED operating hours is reset.

To exit the menu, press MENU, or wait 30 seconds.

Temperature

Select **Temperature**, press ENTER.

The device temperature is displayed.

To exit the menu, press MENU, or wait 30 seconds.

Fan State

Select **Fan State**, press ENTER.

The fan status is displayed.

To exit the menu, press MENU, or wait 30 seconds.

Firmware Version

Select **Firmware Version**, press ENTER.

The firmware version is displayed.

To exit the menu, press MENU, or wait 30 seconds.

RDM UID

Select **RDM UID**, press ENTER.

The RDM UID is displayed.

To exit the menu, press MENU, or wait 30 seconds.

Error Logs

Select **Error Logs**, press ENTER.

Use UP/DOWN button to select **Fixture Errors**, confirm your selection with ENTER.

The error list is displayed.

Use UP/DOWN button to select **Reset Error Log**, confirm your selection with ENTER.

If you wish to reset the relevant error logs, select **Yes**. If you do not wish to reset anything, select **No**. Confirm your selection with ENTER.

If you select **Yes**, use UP/DOWN button to set the password 050, confirm your selection with ENTER. The relevant error logs are reset.

To exit the menu, press MENU, or wait 30 seconds.

Reset Function

Enter the control menu and select **Reset Function**, press ENTER. Use the UP/DOWN button to select **Pan/Tilt Reset**, **Effect Reset** or **All Reset**.

Pan/Tilt Reset

Select **Pan/Tilt Reset**, press ENTER.

Use UP/DOWN button to select **No** or **Yes** (the device will run built-in program to reset pan/tilt to their home positions), confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Effect Reset

Select **Effect Reset**, press ENTER.

Use UP/DOWN button to select **No** or **Yes** (the device will run built-in program to reset effect to their home positions), confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

All Reset

Select **All Reset**, press ENTER.

Use UP/DOWN button to select **No** or **Yes** (the device will run built-in program to reset all to their home positions), confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

Special Function

Enter the control menu and select **Special Function**, press ENTER. Use the UP/DOWN button to select **Factory Restore**.

Factory Restore

Select **Factory Restore**, press ENTER.

If you wish to reset the device to the factory settings, select **Yes**. If you do not wish to reset anything, select **No**. Confirm your selection with ENTER.

To exit the menu, press MENU, or wait 30 seconds.

RDM functions: Certain menus of the device and functions can be called up via the RDM protocol.

The parameter IDs are implemented as follows for different commands:

Parameter ID	Command 'Discovery'	Command 'Set'	Command 'Get'
DISC_UNIQUE_BRANCH	✓		
DISC_MUTE	✓		
DISC_UN_MUTE		✓	
DEVICE_INFO			✓
SUPPORTED_PARAMETERS			✓
SOFTWARE_VERSION_LABEL			✓
DMX_START_ADDRESS		✓	✓
IDENTIFY_DEVICE		✓	✓
DEVICE_MODEL_DESCRIPTION			✓
PARAMETER_DESCRIPTION			✓
MANUFACTURER_LABEL			✓
DEVICE_LABEL		✓	✓
FACTORY_DEFAULTS		✓	✓
BOOT_SOFTWARE_VERSION_ID			✓
BOOT_SOFTWARE_VERSION_LABEL			✓
DMX_PERSONALITY		✓	✓
DMX_PERSONALITY_DESCRIPTION			✓
SLOT_INFO			✓
SLOT_DESCRIPTION			✓
SENSOR_DEFINITION			✓
SENSOR_VALUE			✓
DEVICE_HOURS			✓
PAN_INVERT		✓	✓
TILT_INVERT		✓	✓
RESET_DEVICE		✓	

✓ -Command implemented for the respective parameter ID

5.2 Home Position Adjustment

- ▶ To access the control menus, press the [MENU] button.
- ▶ To access the offset menus, long-press the [ENTER] button.
- ▶ Navigate the offset menus, using the [ENTER], [\blacktriangle UP] and [\triangledown DOWN] buttons.
- ▶ To select a menu option or to confirm a selection, press the [ENTER] button.
- ▶ To return to a higher level in the menu structure without making a change, press the [MENU] button, or wait 30 seconds.

OFFSET MENU	VALUES
Frequency(Hz)	19872~20127
Pan	-128~127
Tilt	-128~127
Zoom	-128~127
Red 1	0~255
Green 1	0~255
Blue 1	0~255
White 1	0~255
.....
Red 5	0~255
Green 5	0~255
Blue 5	0~255
White 5	0~255
LED White 1	0~255
.....
LED White 18	0~255

Frequency(Hz)

Select **Frequency(Hz)**, press ENTER.

Use UP/DOWN button to select a value between 19872 and 20127, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

Pan

Select **Pan**, press ENTER.

Use UP/DOWN button to select a value between -128 and 127, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

Tilt

Select **Tilt**, press ENTER.

Use UP/DOWN button to select a value between -128 and 127, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

Zoom

Select **Zoom**, press ENTER.

Use UP/DOWN button to select a value between -128 and 127, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

Red 1

Select **Red 1**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

Green 1

Select **Green 1**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

Blue 1

Select **Blue 1**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

White 1

Select **White 1**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

.....

Red 5

Select **Red 5**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

Green 5

Select **Green 5**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

Blue 5

Select **Blue 5**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

White 5

Select **White 5**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

LED White 1

Select **LED White 1**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

.....


LED White 18

Select **LED White 18**, press ENTER.

Use UP/DOWN button to select a value between 0 and 255, confirm your selection with ENTER.

To exit the offset menu, press MENU, or wait 30 seconds.

6.1 DMX512 Connection



1. At last unit, the DMX cable has to be terminated with a terminator. Solder a 120-ohm 1/4W resistor between pin 2(DMX-) and pin 3(DMX+) into a 3-pin XLR-plug and plug it in the DMX-output of the last unit.
2. Connect the unit together in a “daisy chain” by XLR plug cable from the output of the unit to the input of the next unit. The cable can only be used in series and cannot be connected in parallel. DMX 512 is a very high-speed signal. Inadequate or damaged cables, soldered joints or corroded connectors can easily distort the signal and shut down the system.
3. The DMX output and input connectors are pass-through to maintain the DMX circuit, when one of the units' power is disconnected.
4. Each lighting unit needs to have a DMX address to receive the data by the controller. The address number is between 1-512.
5. The end of the DMX 512 system should be terminated to reduce signal errors.
6. When wiring 3 pin XLR connectors: Pin 1: GND, Pin 2: Negative signal (-), Pin 3: Positive signal (+). When wiring 5 pin XLR connectors: Pin 1: GND, Pin 2: Negative signal (-), Pin 3: Positive signal (+), Pin4, Pin5 not used.

6.2 Address Setting

If you use a universal DMX controller to control the units, you have to set DMX address between 1 and 512 so that the units can receive DMX signal.

Press the MENU button to access the control menus, select DMX Settings, press the ENTER button to confirm. Use the UP/DOWN button to select DMX Address, press the ENTER button to confirm, the present address will show on the display. Use the UP/DOWN button to adjust the address between 001 and 512, press the ENTER button to store. To exit the menu, press MENU, or wait 30 seconds.

Please refer to the following diagram to address your DMX512 channel for the first 4 units.

Channel Mode	Unit 1 Address	Unit 2 Address	Unit 3 Address	Unit 4 Address
58 channels	1	59	117	175
25 channels	1	26	51	76
23 channels	1	24	47	70
35+ channels (Controlled by DMX)	1	36	71	106
35+ channels (Controlled by Art-Net)	1	21	41	61
27 channels	1	28	55	82
70 channels	1	71	141	211
55 channels	1	56	111	166

6.3 DMX512 Configuration

Please control the fixture by referring to the configurations below.

Attentions:

- ▶ The unit will maintain the last condition until reset if you cut-off the DMX signal.
- ▶ For the channel Function, keep the value for about 3 seconds, then the corresponding function will take into effect.

58/25/23/27/70/55 Channels:

CHANNEL						VALUE	FUNCTION
58ch	25ch	23ch	27ch	70ch	55ch		
1	1	1	1	1	1	000-255	PAN 0°→540°
2	2	2	2	2	2	000-255	PAN FINE
3	3	3	3	3	3	000-255	TILT 0°→450°
4	4	4	4	4	4	000-255	TILT FINE
						000-127 128-189 190-193 194-255	PAN INFINITY Null CCW Rotation, Fast to Slow Stop CW Rotation, Slow to Fast
5	5	5	5	5	5		
6	6	6	6	6	6	000-127 128-189 190-193 194-255	TILT INFINITY Null CW Rotation, Fast to Slow Stop CCW Rotation, Slow to Fast
7	7	7	7	7	7	000-255	PAN/TILT SPEED Fast to Slow
	8	8	8			000-255	RED ALL 0%→100%
	9	9	9			000-255	GREEN ALL 0%→100%
	10	10	10			000-255	BLUE ALL 0%→100%
	11	11	11			000-255	WHITE ALL 0%→100%
8				8	8	000-255	RED 1 0%→100%
9				9	9	000-255	GREEN 1 0%→100%
10				10	10	000-255	BLUE 1 0%→100%
11				11	11	000-255	WHITE 1 0%→100%
				12		000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE 1 Close Open Strobe from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Random Strobe from Slow to Fast Open

				13		000-255	DIMMER 1 0%→100%
				14		000-255	DIMMER FINE 1
12				15	12	000-255	RED 2 0%→100%
13				16	13	000-255	GREEN 2 0%→100%
14				17	14	000-255	BLUE 2 0%→100%
15				18	15	000-255	WHITE 2 0%→100%
				19		000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE 2 Close Open Strobe from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Random Strobe from Slow to Fast Open
				20		000-255	DIMMER 2 0%→100%
				21		000-255	DIMMER FINE 2
16				22	16	000-255	RED 3 0%→100%
17				23	17	000-255	GREEN 3 0%→100%
18				24	18	000-255	BLUE 3 0%→100%
19				25	19	000-255	WHITE 3 0%→100%
				26		000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE 3 Close Open Strobe from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Random Strobe from Slow to Fast Open
				27		000-255	DIMMER 3 0%→100%
				28		000-255	DIMMER FINE 3
20				29	20	000-255	RED 4 0%→100%

21				30	21	000-255	GREEN 4 0%→100%
22				31	22	000-255	BLUE 4 0%→100%
23				32	23	000-255	WHITE 4 0%→100%
				33		000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE 4 Close Open Strobe from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Random Strobe from Slow to Fast Open
				34		000-255	DIMMER 4 0%→100%
				35		000-255	DIMMER FINE 4
24				36	24	000-255	RED 5 0%→100%
25				37	25	000-255	GREEN 5 0%→100%
26				38	26	000-255	BLUE 5 0%→100%
27				39	27	000-255	WHITE 5 0%→100%
				40		000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE 5 Close Open Strobe from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Random Strobe from Slow to Fast Open
				41		000-255	DIMMER 5 0%→100%
				42		000-255	DIMMER FINE 5
28				43	28	000-255	LED WHITE 1 0%→100%
29				44	29	000-255	LED WHITE 2 0%→100%
30				45	30	000-255	LED WHITE 3 0%→100%
31				46	31	000-255	LED WHITE 4 0%→100%

32				47	32	000-255	LED WHITE 5 0%→100%
33				48	33	000-255	LED WHITE 6 0%→100%
34				49	34	000-255	LED WHITE 7 0%→100%
35				50	35	000-255	LED WHITE 8 0%→100%
36				51	36	000-255	LED WHITE 9 0%→100%
37				52	37	000-255	LED WHITE 10 0%→100%
38				53	38	000-255	LED WHITE 11 0%→100%
39				54	39	000-255	LED WHITE 12 0%→100%
40				55	40	000-255	LED WHITE 13 0%→100%
41				56	41	000-255	LED WHITE 14 0%→100%
42				57	42	000-255	LED WHITE 15 0%→100%
43				58	43	000-255	LED WHITE 16 0%→100%
44				59	44	000-255	LED WHITE 17 0%→100%
45				60	45	000-255	LED WHITE 18 0%→100%
							CTO(8000K-2500K)
						000	Null
						001-004	8000K
						005-009	7900K
						010-013	7800K
						014-018	7700K
						019-022	7600K
						023-027	7500K
						028-031	7400K
						032-036	7300K
						037-040	7200K
						041-045	7100K
						046-049	7000K
						050-054	6900K
						055-058	6800K
						059-063	6700K
						064-067	6600K
						068-072	6500K
						073-076	6400K
						077-081	6300K
						082-085	6200K
						086-090	6100K
						091-094	6000K
						095-099	5900K

					100-103 104-108 109-112 113-117 118-121 122-126 127-130 131-135 136-139 140-144 145-148 149-153 154-157 158-162 163-166 167-171 172-175 176-180 181-184 185-189 190-193 194-198 199-202 203-207 208-211 212-216 217-220 221-225 226-229 230-234 235-238 239-243 244-247 248-255	5800K 5700K 5600K 5500K 5400K 5300K 5200K 5100K 5000K 4900K 4800K 4700K 4600K 4500K 4400K 4300K 4200K 4100K 4000K 3900K 3800K 3700K 3600K 3500K 3400K 3300K 3200K 3100K 3000K 2900K 2800K 2700K 2600K 2500K
13	13	13			000-009 010-014 015-019 020-024 025-029 030-034 035-039 040-044 045-049 050-054 055-059 060-064 065-069 070-074 075-079 080-084 085-089 090-094 095-099	COLOR MACRO Open LEE 790-Moroccan Pink LEE 157-Pink LEE 332-Special Rose Pink LEE 328-Follies Pink LEE 345-Fuchsia Pink LEE 194-Surprise Pink LEE 181-Congo Blue LEE 071-Tokyo Blue LEE 120-Deep Blue LEE 079-Just Blue LEE 132-Medium Blue LEE 200-Double CT Blue LEE 161-State Blue LEE 201-Full CT Blue LEE 202-Half CT Blue LEE 117-Steel Blue LEE 353-Lighter Blue LEE 118-Light Blue

						100-104 105-109 110-114 115-119 120-124 125-129 130-134 135-139 140-144 145-149 150-154 155-159 160-164 165-169 170-174 175-179 180-201 202-207 208-229 230-234 235-239 240-244 245-249 250-255	LEE 116-Medium Blue Green LEE 124-Dark Green LEE 139-Primary Green LEE 089-Moss Green LEE 122-Fern Green LEE 738-JAS Green LEE 088-Lime Green LEE 100-Spring Yellow LEE 104-Deep Amber LEE 179-Chrome Orange LEE 105-Orange LEE 021-Gold Amber LEE 778-Millennium Gold LEE 135-Deep Gold Amber LEE 164-Flame Red Open CW Rotation, Fast to Slow Stop CCW Rotation, Slow to Fast Open Random Color: Fast Random Color: Medium Random Color: Slow Open
46	14	14	61			000-004 005-009 010-014 015-019 020-024 025-029 030-034 035-039 040-044 045-049 050-054 055-059 060-064 065-069 070-074 075-079 080-084 085-089 090-094 095-099 100-104 105-109 110-114 115-119 120-124 125-129 130-134 135-139 140-144	PIXEL EFFECT SELECT Open LED1 LED2 LED3 LED4 LED5 LED1+2 LED2+3 LED3+4 LED4+5 LED1+3 LED2+4 LED3+5 LED1+4 LED2+5 LED1+2+5 LED1+2+4 LED1+2+3 LED2+3+4 LED3+4+5 LED1+4+5 LED1+2+5 LED1+2+4+5 LED1+2+3+4 LED2+3+4+5 LED1+3+4+5 LED1+2+3+4+5 Built-in Mode 1 Built-in Mode 2

						145-149 150-154 155-159 160-164 165-169 170-174 175-179 180-184 185-189 190-194 195-199 200-204 205-209 210-214 215-219 220-224 225-229 230-234 235-239 240-244 245-255	Built-in Mode 3 Built-in Mode 4 Built-in Mode 5 Built-in Mode 6 Built-in Mode 7 Built-in Mode 8 Built-in Mode 9 Built-in Mode 10 Built-in Mode 11 Built-in Mode 12 Built-in Mode 13 Built-in Mode 14 Built-in Mode 15 Built-in Mode 16 Built-in Mode 17 Built-in Mode 18 Built-in Mode 19 Built-in Mode 20 Randomly Light Up a Pixel Randomly Light Up two Pixels Null
47	15		15	62		000-127 128-189 190-193 194-255	PIXEL EFFECT SPEED Null Fast to Slow Stop Slow to Fast
48				63		000-009 010-014 015-019 020-024 025-029 030-034 035-039 040-044 045-049 050-054 055-059 060-064 065-069 070-074 075-079 080-084 085-089 090-094 095-099 100-104 105-109 110-114 115-119 120-124 125-129 130-134 135-139	BACKGROUND COLOR Open LEE 790-Moroccan Pink LEE 157-Pink LEE 332-Special Rose Pink LEE 328-Follies Pink LEE 345-Fuchsia Pink LEE 194-Surprise Pink LEE 181-Congo Blue LEE 071-Tokyo Blue LEE 120-Deep Blue LEE 079-Just Blue LEE 132-Medium Blue LEE 200-Double CT Blue LEE 161-State Blue LEE 201-Full CT Blue LEE 202-Half CT Blue LEE 117-Steel Blue LEE 353-Lighter Blue LEE 118-Light Blue LEE 116-Medium Blue Green LEE 124-Dark Green LEE 139-Primary Green LEE 089-Moss Green LEE 122-Fern Green LEE 738-JAS Green LEE 088-Lime Green LEE 100-Spring Yellow

						140-144 145-149 150-154 155-159 160-164 165-169 170-174 175-179 180-201 202-207 208-229 230-234 235-239 240-244 245-249 250-255	LEE 104-Deep Amber LEE 179-Chrome Orange LEE 105-Orange LEE 021-Gold Amber LEE 778-Millennium Gold LEE 135-Deep Gold Amber LEE 164-Flame Red Open CW Rotation, Fast to Slow Stop CCW Rotation, Slow to Fast Open Random Color: Fast Random Color: Medium Random Color: Slow Open
49	16	19	16	64	46	000-005 006-255	INTENSITY Blackout Flash Intensity, minimum to maximum
50	17	20	17	65	47	000-255	DURATION Flash Duration, minimum to maximum
51	18	21	18	66	48	000-005 006-255	RATE No Flash Flash Rate, Slow to Fast
52	19	22		67	49	000-005 006-050 051-100 101-150 151-200 201-255	EFFECTS Null Ramp Up Ramp Down Ramp Up-Down Lightning Random
			19			000-005 006-050 051-100 101-150 151-200 201-255	EFFECTS 1 Null Ramp Up Ramp Down Ramp Up-Down Lightning Random
			20			000-004 005-009 010-014 015-019 020-024 025-029 030-034 035-039 040-044 045-049 050-054 055-059 060-064 065-069	EFFECTS 2 Null Show 1 Show 2 Show 3 Show 4 Show 5 Show 6 Show 7 Show 8 Show 9 Show 10 Show 11 Show 12 Show 13

						070-074 075-079 080-084 085-089 090-094 095-099 100-104 105-109 110-114 115-119 120-124 125-129 130-134 135-139 140-144 145-149 150-154 155-159 160-164 165-169 170-174 175-179 180-184 185-189 190-194 195-199 200-204 205-209 210-214 215-219 220-224 225-229 230-234 235-239 240-244 245-255	Show 14 Show 15 Show 16 Show 17 Show 18 Show 19 Show 20 Show 21 Show 22 Show 23 Show 24 Show 25 Show 26 Show 27 Show 28 Show 29 Show 30 Show 31 Show 32 Show 33 Show 34 Show 35 Show 36 Show 37 Show 38 Show 39 Show 40 Show 41 Show 42 Show 43 Show 44 Show 45 Show 46 Randomly Light Up a Pixel Randomly Light Up two Pixels Null
			21			000-127 128-189 190-193 194-255	EFFECTS 2 SPEED Null Fast to Slow Stop Slow to Fast
53	20	14	22	68	50	000-255	ZOOM Wide→Narrow
54	21	15	23	69	51	000-255	ZOOM FINE
55	22	16	24		52	000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239	STROBE Close Open Strobe from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open

						240-247 248-255	Random Strobe from Slow to Fast Open
56	23	17	25		53	000-255	DIMMER 0%→100%
57	24	18	26		54	000-255	DIMMER FINE
						000-029 030-039 040-049 050-059 060-069 070-079 080-089 090-099 100-109 110-119 120-139 140-149 150-159 160-199 200-209 210-219 220-229 230-255	FUNCTION Null Dimmer Curve Linear Dimmer Curve Square Law Dimmer Curve Inv SQ Law Dimmer Curve S Line Power Mode: Off Line Power Mode: On Null Led Frequency Setting Enable Led Frequency Setting Disable Null Pan/Tilt Reset Effect Reset Null Reset All Dimmer Speed: Fast Dimmer Speed: Smooth Null
58	25	23	27	70	55		

35+ Channels:

CHANNEL	VALUE	FUNCTION
Controlled by DMX		
1	000-255	PAN 0°→540°
2	000-255	PAN FINE
3	000-255	TILT 0°→450°
4	000-255	TILT FINE
5	000-127 128-189 190-193 194-255	PAN INFINITY Null CCW Rotation, Fast to Slow Stop CW Rotation, Slow to Fast
6	000-127 128-189 190-193 194-255	TILT INFINITY Null CW Rotation, Fast to Slow Stop CCW Rotation, Slow to Fast
7	000-255	PAN/TILT SPEED Fast to Slow
8		LED WHITE 1

	000-255	0%→100%
9	000-255	LED WHITE 2 0%→100%
10	000-255	LED WHITE 3 0%→100%
11	000-255	LED WHITE 4 0%→100%
12	000-255	LED WHITE 5 0%→100%
13	000-255	LED WHITE 6 0%→100%
14	000-255	LED WHITE 7 0%→100%
15	000-255	LED WHITE 8 0%→100%
16	000-255	LED WHITE 9 0%→100%
17	000-255	LED WHITE 10 0%→100%
18	000-255	LED WHITE 11 0%→100%
19	000-255	LED WHITE 12 0%→100%
20	000-255	LED WHITE 13 0%→100%
21	000-255	LED WHITE 14 0%→100%
22	000-255	LED WHITE 15 0%→100%
23	000-255	LED WHITE 16 0%→100%
24	000-255	LED WHITE 17 0%→100%
25	000-255	LED WHITE 18 0%→100%
26	000-005 006-255	INTENSITY Blackout Flash Intensity, minimum to maximum
27	000-255	DURATION Flash Duration, minimum to maximum
28	000-005 006-255	RATE No Flash Flash Rate, Slow to Fast
29	000-005 006-050 051-100 101-150 151-200 201-255	EFFECTS Null Ramp Up Ramp Down Ramp Up-Down Lightning Random

30	000-255	ZOOM Wide→Narrow
31	000-255	ZOOM FINE
32	000-007	STROBE
	008-015	Close
	016-131	Open
	132-139	Strobe from Slow to Fast
	140-181	Open
	182-189	Slow Open Fast Close from Slow to Fast
	190-231	Open
	232-239	Fast Open Slow Close from Slow to Fast
	240-247	Open
	248-255	Random Strobe from Slow to Fast
33	000-255	DIMMER 0%→100%
34	000-255	DIMMER FINE
35	000-029	FUNCTION
	030-039	Null
	040-049	Dimmer Curve Linear
	050-059	Dimmer Curve Square Law
	060-069	Dimmer Curve Inv SQ Law
	070-079	Dimmer Curve S
	080-089	Line Power Mode: Off
	090-099	Line Power Mode: On
	100-109	Null
	110-119	Led Frequency Setting Enable
	120-139	Led Frequency Setting Disable
	140-149	Null
	150-159	Pan/Tilt Reset
	160-199	Effect Reset
	200-209	Null
	210-219	Reset All
	220-229	Dimmer Speed: Fast
	230-255	Dimmer Speed: Smooth
		Null
Controlled by Art-Net		
1	000-255	RED 1 0%→100%
2	000-255	GREEN 1 0%→100%
3	000-255	BLUE 1 0%→100%
4	000-255	WHITE 1 0%→100%
5	000-255	RED 2 0%→100%
6	000-255	GREEN 2 0%→100%
7		BLUE 2

	000-255	0%→100%
8	000-255	WHITE 2 0%→100%
9	000-255	RED 3 0%→100%
10	000-255	GREEN 3 0%→100%
11	000-255	BLUE 3 0%→100%
12	000-255	WHITE 3 0%→100%
13	000-255	RED 4 0%→100%
14	000-255	GREEN 4 0%→100%
15	000-255	BLUE 4 0%→100%
16	000-255	WHITE 4 0%→100%
17	000-255	RED 5 0%→100%
18	000-255	GREEN 5 0%→100%
19	000-255	BLUE 5 0%→100%
20	000-255	WHITE 5 0%→100%

07/ Error Information

Error codes are shown continuously in the display when the fixture fails and they will not disappear until the fixture is repaired.

CPU-B/C/D Error

- Check whether the 485 (DATA) leads on the PCB board are installed in place or disconnected.
- Check whether the related 485 (DATA) signal circuit on the PCB board is damaged.

Pan Reset Error

- Check whether the position of the pan where the magnet is installed falls off or is damaged.
- Check whether there are obstacles in the pan operating range.
- Check whether the Hall element on the pan is damaged.
- Check whether the lead connecting the Hall element on the pan and the PCB board is in poor contact or disconnected.
- Check whether the motor on the pan is damaged.
- Check whether the related circuit of the motor drive board on the pan is damage.

Pan Encode Error

- Check whether the encoder on the pan is damaged.
- Check whether the lead connecting the encoder on the pan and the PCB board is in poor contact or disconnected.

Tilt Reset Error

Check whether the position of the tilt where the magnet is installed falls off or is damaged.

Check whether there are obstacles in the tilt operating range.

Check whether the Hall element on the tilt is damaged.

Check whether the lead connecting the Hall element on the tilt and the PCB board is in poor contact or disconnected.

Check whether the motor on the tilt is damaged.

Check whether the related circuit of the motor drive board on the tilt is damage.

Tilt Encode Error

Check whether the encoder on the tilt is damaged.

Check whether the lead connecting the encoder on the tilt and the PCB board is in poor contact or disconnected.

Zoom Error

Check whether the position of the zoom where the magnet is installed falls off or is damaged.

Check whether there are obstacles in the zoom operating range.

Check whether the Hall element on the zoom is damaged.

Check whether the lead connecting the Hall element on the zoom and the PCB board is in poor contact or disconnected.

Check whether the motor on the zoom is damaged.

Check whether the related circuit of the motor drive board on the zoom is damage.

LED Temp. 1/2 Error

- Check whether the temperature detecting board is normal.
- Check whether the components of the temperature detecting board are damaged.
- Check whether the lead on the temperature detecting board is installed in place or disconnected.

LED Timeout Use

LED Too Hot Off

- When the fixture temperature of beam mode reaches 75°C, it will automatically turn off to protect the fixture.
- When the fixture temperature of strobe mode reaches 100°C, it will automatically turn off to protect the fixture.


Base Fan1/2 Start Error

- Check whether the fan is not running.
- Check whether the fan leads are installed in place or disconnected.
- Check whether the fan is damaged.
- Check whether there are obstacles in the fan operating range.

Head Fan 1/2/3/4/5 Start Error

- Check whether the fan is not running.
- Check whether the fan leads are installed in place or disconnected.
- Check whether the fan is damaged.
- Check whether there are obstacles in the fan operating range.

Position of cooling fans:



08/ Troubleshooting

Following are a few common problems that may occur during operation. Here are some suggestions for troubleshooting:

A. The unit does not work, no light and the fan does not work

- ▶ Check the connected power.
- ▶ Measure the voltage.
- ▶ Check the power indicator to see whether it can be lit up or not.

B. Not responding to the DMX controller

- ▶ Check whether the DMX connectors and the DMX cables are connected correctly.
- ▶ Check whether the DMX address is correctly set.
- ▶ If the intermittent DMX signal problem occurs, check whether the XLR socket and the signal cable are well connected.
- ▶ Try it with another DMX controller.
- ▶ Check whether the DMX cables run near or alongside to the high-voltage cables, which may damage or interfere with the signal circuit.

C. One of the channels is not working well

- ▶ The stepper motor might be damaged or the cable connected to the PCB might be broken.
- ▶ The motor's drive IC on the PCB might be out of condition.

09/ Fixture Cleaning

It is absolutely essential that the fixture is kept clean to ensure the maximum light-output and allow the fixture to function reliably throughout its life. The fixture must be cleaned regularly to avoid dust, dirt and smoke-fluid residues building up on or within the fixture. The cleaning frequency depends on the application environment. Clean the fixture immediately if the dust enters it to avoid damage to the optical lens due to excessive dust.

- ▶ A soft lint-free cloth moistened with any good glass cleaning fluid is recommended, under no circumstances should solvents be used.
- ▶ Always dry the parts carefully.
- ▶ Clean the external optical lens at least every 20 days.

Declaration of Conformity

We declare that our products (lighting equipments) comply with the following specification and bears CE mark in accordance with the provision of the Electromagnetic Compatibility (EMC) Directive 2014/30/EU.

EN 55032: 2015+A11: 2020; EN IEC 61000-3-2: 2019;
EN 61000-3-3: 2013+A1: 2019;
EN 55035: 2017+A11: 2020.

& Harmonized Standard

EN 60598-1: 2015+A1: 2018;
EN 60598-2-17: 2018; EN 62493: 2015.
Safety of household and similar electrical appliances
Part 1: General requirements and tests

Certifications
cETLus Approved (Control #5000057)

