		Use	r Guide of CA-8 Easy	Controller	
Apply to	Spot Emperor	Fantasy	Falcon	Streamer laser	
CA-8 Button description	2) FUNCTION 3) MODE	1; STAND BY 2; FUNCTION 3) MODE	1) STAND BY 2) FUNCTION 3) MODE	1) STAND BY 2: FUNCTION 3) MODE	
	Functions:	Functions:	Functions:	Functions:	
CA-8 easy controller	-STAND BY: Blackout all units. -STROBE/NEXT/ STROBE: Under Show1 & Show2 modes, the lights will strobe in three different ways: a.) Strobe in different gobos and colors. b.) Synchronous strobe. c.) 2-light strobe. If the unit is in Slow Mode, Press Next button for color and gobo selection. -SHOW1/ SLOW/ SHOW2: (All triggered by music.) a.) Show 1 (LED off) — The tilt with 210 wide angle scan. b.) Slow (LED on) — Movement in slow motion.	-STAND BY: Blackout all units. -STROBE/NEXT/ MOVING: i.) Under Audio mode, press Strobe button for strobing. ii.) Under Slow mode, press Next button for color selection. iii.) Under Position mode, press Moving button for Pan/Tilt position and Dimmer effect selection. First press, for Pan, second for Tilt, third press for Dimmer. Next three press for Slave units if the slave units are set in 2-light show contrary to the master unit. If the slave units are synchronous to the master	-STAND BY. Blackout all units. -STROBE/NEXT: Under Fast mode, the light will strobe in three different ways: a.) Strobe in different gobos and colors. b.) Synchronous strobe. c.) 2-light strobe. Under Slow mode, press Next button for color and gobo selection. -FAST/SLOW: In Fast mode (LED off), the unit's movement is sound activated. In Slow mode (LED on), press Next button for color or gobo selection.	-STAND BY: Blackout all units. -STROBE/NEXT: Under Fast/Slow mode, the light provides 6 different effects, press Next button to choose desired effect. -FAST/SLOW: In Fast mode (LED off), the unit's Pan/Barrel is sound activated; Pan moves fast. In Slow mode (LED on), Pan/Barrel is sound activated but Pan moves slowly.	07 11 24
	c) Show 2 (LED blinking)- The tilt with 90' scan.	unit, the second three press (button presses) will be no function.	Å + s +	F-17-2 1 474 2 1	The real part of the second
		-AUDIO/SLOW/ POSITION i.)Audio (LED off)- operation triggered by music. ii.)Slow (LED on) — movement in slow motion. iii.)Position (LED blinking) Pan/Tilt positions and Dimmer status selection.	ALAI	大小河流	又文直