


4.3 DMX 512 Configuration

14 channel mode:

14 Channels						
Ch1	Ch2	Ch3	Ch4	Ch5	Ch6	Ch7
Pan	Pan Fine	Tilt	Tilt Fine	P/T Speed	Reset	Dimmer
<p>255 540° 0 0°</p>	<p>255 0</p>	<p>255 220° 0 0°</p>	<p>255 0</p>	<p>255 Slow 0 Fast</p>	<p>015-255 No function</p> <p>010-014 Reset all</p> <p>000-009 No function</p>	<p>255 100% 0 0%</p>
Ch8		Ch9	Ch10	Ch11	Ch12	
Shutter		Beam Red	Beam Green	Beam Blue	Beam White	
<p>245-255 open 230-244 burst 225-229 open 210-224 sine wave 205-209 open 190-204 random burst pulse 185-189 open 170-184 burst pulse 165-169 open 150-164 random closing pulse 145-149 open 130-144 random opening pulse 125-129 open 110-124 random strobe 105-109 open 090-104 closing pulse 085-089 open 070-084 opening pulse 065-069 open 025-064 strobe 020-024 open 000-019 closed</p>		<p>255 100% 0 0%</p>	<p>255 100% 0 0%</p>	<p>255 100% 0 0%</p>	<p>255 100% 0 0%</p>	

Color wheel effect	
Ch 13	000-009 Open
	010-014 LEE 790 - Moroccan pink
	015-019 LEE 157 - pink
	020-024 LEE 332 - Special rose pink
	025-029 LEE 328 - Follies pink
	030-034 LEE 345 - Fuchsia pink
	035-039 LEE 194 - Surprise pink
	040-044 LEE 181 - Congo blue
	045-049 LEE 071 - Tokyo blue
	050-054 LEE 120 - Deep blue
	055-059 LEE 079 - Just blue
	060-064 LEE 132 - Medium blue
	065-069 LEE 200 - Double CT blue
	070-074 LEE 161 - State blue
	075-079 LEE 201 - Full CT blue
	080-084 LEE 202 - Half CT blue
	085-089 LEE 117 - Steel blue
	090-094 LEE 353 - Lighter blue
	095-099 LEE 118 - Light blue
	100-104 LEE 116 - Medium blue green
	105-109 LEE 124 - Dark green
	110-114 LEE 139 - Primary green
	115-119 LEE 089 - Moss green
	120-124 LEE 122 - Fern green
	125-129 LEE 738 - JAS green
	130-134 LEE 088 - Lime green
	135-139 LEE 100 - Spring yellow
	140-144 LEE 104 - Deep amber
	145-149 LEE 179 - Chrome orange
	150-154 LEE 105 - Orange
	155-159 LEE 021 - Gold amber
	160-164 LEE 778 - Millennium gold
	165-169 LEE 135 - Deep gold amber
	170-174 LEE 164 - Flame red
	175-179 Open
Color wheel rotation effect	
180-201 Clockwise, fast to slow	
202-207 Stop (this will stop wherever the color is at the time)	
208-229 Counter-clockwise, slow to fast	
230-234 Open	
Random color	
235-239 Fast	
240-244 Medium	
245-249 Slow	
250-255 Open	
Zoom	
Ch 14	000-255  →  → 