

CHANNEL		VALUE	FUNCTION
4ch	6ch		
1	1	000-255	DIMMER 0%→100%
	2	000-255	DIMMER FINE
2	3	000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE Close Open Strobe from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Random Strobe from Slow to Fast Open
3	4	000-255	ZOOM Narrow→Wide
	5	000-255	ZOOM FINE
4	6	000-029 030-039 040-049 050-059 060-069 070-099 100-109 110-119 120-122 123 124 125 126 127 128 129 130 131 132 133	SPECIAL FUNCTION (To activate following functions, stop in DMX value for at least 3 seconds.) Null Dimmer Curve: Linear Dimmer Curve: Square Law Dimmer Curve: Inv SQ Law Dimmer Curve: S Curve Null Led Frequency Setting Enable Led Frequency Setting Disable Null 900Hz 1000Hz 1100Hz 1200Hz 1300Hz 1400Hz 1500Hz 2500Hz 4000Hz 5000Hz 6000Hz

		134	10KHz
		135	15KHz
		136	20KHz
		137	25KHz
		138-199	Null
		200-209	Reset All
		210-219	Dimmer Speed: Fast
		220-229	Dimmer Speed: Smooth
		230-255	Null